



Installing Your Ultra H₂O System

Ultra H₂O is an easy to use, easy to install countertop system. Follow these simple instructions and you will have activated water in minutes!

1. Each Ultra H₂O System comes with a faucet diverter which is about 1" wide and 2" high. (The exact thread size is 15/16" with 27 threads per inch and is a male fitting.) The diverter fits almost all standard faucets and comes with a couple of spare adaptors in case they are needed.
2. Screw diverter directly on to your faucet head.
3. Each unit also comes with a length of plastic hosing. This piece attaches directly from the Ultra H₂O system to the diverter and is what moves the tap water into the system. Connect this hose to the diverter and the Ultra H₂O system.
4. Turn the diverter valve so that the water flows to the Ultra H₂O system, and let it run for a minimum of 2 minutes. *Flushing the system is important before your first use.* You may see water discoloration occur within the first minute.



Use the extra ties to secure the hose to the faucet so that it doesn't hang down in your sink.



*Ultra H₂O may last up to two years depending on usage and water quality before you need to replace the filters. Occasional testing of the pH and ORP is recommended. See back for testing instructions.

For customer service, we can be reached at 816-876-2573 M-F 8am - 6pm CST or online at www.myui.com.

ORP/pH Indication Test

This test indicates that your Ultra H₂O system is producing "active water". If the water fails to turn a dark purple color, it is time to replace the Ultra H₂O cartridge.

New cartridges may be ordered by calling 816-876-2573 or visiting our website, <http://www.myui.com>

PROCEDURE:

CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.

KEEP REAGENTS AWAY FROM CHILDREN.

Ph/-ORP Indicator Test Reagent

1. Add 2 ounces of water to a disposable water vessel.
2. Add 3 drops of R-1003U Long Range Indicator, swirl to mix. Sample will turn purple if pH Alkalinity is present above an 8.5 level.

Note: Tests using an ORP meter indicate that water processed by the Ultra H₂O system with a pH above 8.5 results in a Negative ORP level.

Cleaning H₂O To Go

If the water used is water from the Ultra H₂O unit, H₂O To Go will perform at its best, and should only need cleaning about every 2 weeks. If the water used is bottled or tap water then Ultra H₂O To Go will need cleaning about every 4-5 days.

Ultra H₂O To Go acts best as an extender of the already clean and alkaline/antioxidant water created by the Ultra H₂O unit. It will alkalize/antioxidant tap water if left in the water 12 hours before drinking, but won't remove any chlorine, heavy metals, or contaminants. Using Tap water will greatly decrease the life of Ultra H₂O To Go.

To clean Ultra H₂O To Go

1. Place it in a large bowl or container
2. Fill water over the top of the stick
3. Add White Vinegar to the water at about a 30% ratio
4. Briskly shake and move Ultra H₂O To Go thru the water and vinegar solution for about 2 minutes. This will clean Ultra H₂O and the water should turn a white milky color.
5. Remove Ultra H₂O To Go from the solution and rinse thoroughly.

Ultra H₂O To Go is now ready for reuse. Do not leave Ultra H₂O To Go in the solution for an extended time. With proper cleaning and usage, you should get about 6 months use from Ultra H₂O To Go.